



- Designed for land seismic survey operations
- Powerful stakeout capabilities including grid-based navigation and zero calculation offsets
- Notifications and warnings when operating in exclusion zones

Stakeout Accurately and Efficiently

The surveying aspects of a land seismic survey demand accuracy and production speed. The Trimble Access™ Land Seismic Module is designed to simplify seismic stakeout work to increase speed and reduce errors.

Streamlined Workflow

The easy to follow workflow for Trimble Access Land Seismic uses common naming conventions for stakeout points. The unique bin-based navigation functionality ensures that operators get to the next stake location quickly and that points are marked within the tolerances intended by the seismic survey design.

Easy Offsetting

Often, conditions encountered in the field require that stake locations be offset from the design location. The stakeout screen provides simple inline/crossline deltas for navigation to the point to be staked. These inline/crossline deltas can be used to navigate easily to an exact offset location without performing any calculations. If an offset location needs to be staked, the current bin deltas can be used to navigate directly to the offset. The current bin area of the navigation display shows the currently occupied bin number and the inline/crossline deltas to its center, greatly improving the speed and accuracy of positioning offset points. Calculation of offset coordinates is not required by the operator – just use the navigation deltas displayed at all times.


GPSeismic Compatibility

Trimble Access Land Seismic uses the grid definition files (.GDF), crooked line files (.CRK), and exclusion zone files (.XZO) produced by GPSeismic. GDF and CRK files provide the basis for inline and crossline navigation during stakeout. In addition GDF files provide dynamic offsetting and the ability to key in new points using the bin and track name to calculate the coordinates. File conversions are not necessary, all files are read directly.


After stakeout, data files from Trimble Access and Trimble Business Center software can be imported directly into GPSeismic to quickly compile postplot records.

Exclusion Zone Monitoring and Creation

Trimble Access Land Seismic uses GPSeismic .XZO exclusion zone files during stakeout to warn the operator if they enter an



exclusion zone, and warn again if they try staking a point in an exclusion zone. To measure a point in an exclusion zone, the operator must purposely override warnings. Any point measured in an exclusion zone is labeled indicating it is within an exclusion zone boundary. Exclusion zones are also displayed in the map. New exclusion files can be created from the map, or existing exclusion zone files can be edited using the map.



Trimble Access Land Seismic can:


- Stake and offset preplot points with ease
- Utilize .GDF .CRK and .XZO files created by GPSeismic
- Increase safety through the use of exclusion zone files, and the real-time update of exclusion zone files in the field

Designed for Real World Productivity


Trimble Access Land Seismic is built to allow surveyors to perform their specialized tasks associated with a land seismic survey. The workflow and screen layouts do not include elements that are not needed in this specialized type of surveying. Operators have the tools they need to perform their job quickly, accurately, and efficiently.

Key Features

Feature	Details
Grid-based Navigation	<ul style="list-style-type: none"> Simple navigation to the stake location using inline and crossline deltas Calculation-free navigation to offset locations Clear display of deltas to the center of the occupied bin
Layout Tolerances	<ul style="list-style-type: none"> Inline and Crossline deltas are colored green when within specific layout tolerance
Exclusion Zone Monitoring	<ul style="list-style-type: none"> Points cannot be accidentally staked in an exclusion zone Vivid operator warnings
Smart Point Sequencing	<ul style="list-style-type: none"> Supports half stations Supports alpha characters
Key in Grid points	<ul style="list-style-type: none"> Key in points using the bin and track name and have the coordinates calculated via the GDF file
Map	<ul style="list-style-type: none"> Display of preplots, surveyed points and exclusion zones Exclusion zone files can be created or appended to from the map
Full Integration with GPSeismic	<ul style="list-style-type: none"> GDF – Grid definition files XZO – Exclusion zone files CRK – Crooked line files



Red deltas indicate operation in an exclusion zone



Industry-standard point naming and use of grid definition files